

Map Production Pro User Guide

FEMA DFIRM Production Tools





Table of Contents:

Vhat is Map Production Pro?	3
lap Production Pro Overview	3
Quick Reference Guide	
ool Controls	
Map Production Pro Toolbar	5
Map Production Pro Tools	
Create Layout	5
Clear Graphics	5
Print to PDF	5
Cancel	
Map Production Pro Interface Sections	6
Panel	
Include Additional Elements	
Logo Style	
Frame Style	
Frame Size Date	
Page Orientation	
Initial Countywide Date	
Base Map Note	
DF Export Toolbar	
·	
DDE Evenort	10
PDF Export	
rouble – Shooting	
Contacts	. 11

What is Map Production Pro?

Map Production Pro is a tool that automates production of DFIRM and LOMR panels once a DFIRM database has been completed. This tool will render all features on the selected panel, load the appropriate annotation layers, and automatically generate tables needed for the DFIRM index. There are several options that are available to users, allowing for the customization of the layout according to the characteristics of the panel. These panel elements meet FEMA's FIRM layout standards, which are described in FEMA's April 2003 *Guidelines and Specifications for Flood Hazard Mapping Partners Appendix K: Format and Specifications for Flood Insurance Rate Maps*.




Map Production Pro Overview

The Map Production Pro user guide contains useful information that will help guide you through using the tool. The key sections of this guide are:

- Quick user reference guide (p. 4)
- Descriptions of tools and how to use them (p. 5)
- Support/contact information (p. 9)

Quick Reference Guide

The following is a quick reference guide to all of the components of **Map Production Pro**. You can prepare DFIRM or LOMR panels for printing.





Tool Controls

Now that you are ready to print DFIRM panels, you will need to know how to create them using Map Production Pro.

Map Production Pro Toolbar



The Map Production Pro Toolbar has a single icon. When you select it, the Map Production Pro interface will open, displaying the tools and options available for printing DFIRM and LOMR FIRM panels.

Map Production Pro Tools











Create Layout

View the FIRM panel layout. The layout will be generated for the selected panel and the view will be switched to "Layout."

Note: Hide any suppressed text before printing the panel. Turn off the annotation layer in the table of contents that ends with the **SUP** suffix.



Clear Graphics

After previewing a panel remove all graphics from the layout page before previewing another panel.



Print to PDF

Print the selected panel to PDF. The panel will be printed with the following naming conventions

For LOMRs: L(CID)_(Panel#).pdf = **L06063C_0225.pdf**

For DFIRMs: D(CID)_(Panel#).pdf = **D06063C_0225.pdf**

Use the <u>PDF Export</u> tool to download the PDF to your local drive for printing or archiving. Refer to page 8 of this user guide for more information on this tool.

Note: Hide any suppressed text before printing the panel. Turn off the annotation layer in the table of contents that ends with the **_SUP** suffix.




Cancel out of Map Production Pro.

Map Production Pro Interface Sections

A brief description of each of the sections contained in the Map Production Pro interface is provided below. The options, in each section, may vary between the DFIRM and LOMR tab.

Panel

Select a panel number from the list. You can choose to view the Printed Panels only or All Panels in the FIRM Panel Index.



Include Additional Elements





CBRS Note

If the map panel is in a location for which a Coastal Barriers Resource (CBRS) note would be appropriate, check the box. The note will be added to the Title Block, in the location indicated by the red horizontal line shown in the icon next to the CBRS Note checkbox.

Legend Note

This option is available only when you are creating a full size LOMR panel with the Old Style frame.

Logo Style





Choose to display the DHS or FEMA logo in the Title Block.

Guidelines:

- a. For a LOMR, use the same logo on the new map that appears on the old.
- b. If only part of the DFIRM is being republished, use the same logo on the new map that appears on the old.
- c. If this is a new DFIRM, use the DHS logo.


Frame Style






The frame style for DFIRM panels is set and cannot be modified. For LOMR panels, you can use the New Style Title Block or the Old Style. The New Style will always include a community listing. If you are printing the LOMR at full size and use an Old Style title block, you should show the community listing for a countywide and omit it for a single jurisdiction.

Frame Size




The frame size for DFIRM panels is set and cannot be modified. There are several options for printing LOMR panels. If you choose to print a Full Panel Frame, you will have additional options for page dimensions. Click on the **Properties** button to select the dimensions.



LOMR panel frame size options available

Date



Select to show the Effective Date or the Map Revised date.

Page Orientation




Select a Portrait or Landscape orientation for a LOMR panel. DFIRMs are printed in landscape orientation only.

Initial Countywide Date




Select to show the initial countywide date on the DFIRM panel. This option will only be available for countywide studies. Upon checking this box, if there is a date in the corresponding table, it will be displayed for the user, who can then edit it if necessary. Once the user previews a panel, any changes made in the date window will be committed to the appropriate table in the geodatabase.

Base Map Note



This will allow the user to view, add, or update the base map note for the panel. This option only appears on the DFIRM tab. When the user clicks on the "View Note" button, the following dialog appears:



Upon selecting **View Note**, if there is a base map note in the corresponding table, it will be displayed for the user, who can then edit it if necessary. Once the user previews a panel, any changes made in the base map note window will be committed to the appropriate table in the geodatabase.

If working on a LOMR, the user will have to switch to the DFIRM tab to enter/edit base map note information.

PDF Export Toolbar



Once you have printed your selected panels to PDF, you can retrieve and save them to a local drive or server using the PDF Export Tool. You can print the PDF work maps to your local plotter, share them electronically, or store them in an archive.



PDF Export

Allows users to download single or multiple PDF files. Use this tool after printing panels to PDF using Map Production Pro's <u>Print</u> feature.

Trouble - Shooting

Problem: Features appear outside of the map frame in Layout view.

Solution: Make sure that the FIRM PANEL feature class is turned on in the table of contents –

these features act as a mask, covering all features outside of the panel that you have

selected.

Contacts

If you need assistance with this tool, please contact the representative at your local RMC.

Name	Role	Email	Phone
REGION I	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		1
Brent McCarthy	Lead	bmccarthy@watershedconcepts.com	336-240-7339
Jeffrey Burm	GIS/Mapping	jburm@watershedconcepts.com	517-482-4930 x4752
REGION II			
Rich Cassin	Operations Manager	Rich.Cassin@mapmodteam.com	914-333-5366
Michael Crino	GIS/Mapping	mcrino@mbakercorp.com	718-482-9945
REGION III			
Mike Conaboy	Operations Manager	mconaboy@mbakercorp.com	609-734-7922
Lee Brancheau	GIS/Mapping	lbrancheau@mbakercorp.com	609-734-7912
REGION IV			•
Stephen King	Operations Manager	Stephen.King@mapmodteam.com	678-459-1004
Heather Williams	GIS/Mapping	hwilliams@watershedconcepts.com	770-454-5600 x4914
REGION V			
Sujata Banerjee	Business Manager	Sujata.Banerjee@mapmodteam.com	312-575-3902
Pam Coye	GIS/Mapping	pcoye@mbakercorp.com	312-575-3913
REGION VI			
Dan Hoecker	Operations Manager	Dan.Hoecker@mapmodteam.com	940-783-4126
Phil Nguyen	GIS/Mapping	pxnguyen@mbakercorp.com	940-783-4121
REGION VII			
Matthew Koch	Operations Manager	mkoch@watershedconcepts.com	816-502-9420 x4952
Rod Odom	GIS/Mapping	rodom@watershedconcepts.com	816-502-9420 x4957
REGION VIII			
David Jula	Operations Manager	David.Jula@mapmodteam.com	720-514-1101
Mike Garner	GIS/Mapping	mgarner@mbakercorp.com	720-514-1105
REGION IX			
Travis Clark	Business Manager	Travis.Clark@mapmodteam.com	703-317-6535
Michael Skowronek	GIS/Mapping	michael.skowronek@mapmodteam.com	510-879-0958
REGION X			
Michael Morgan	Business Manager	Mike.Morgan@mapmodteam.com	206-254-5600
Timothy Witten	GIS/Mapping	wittentd@bv.com	206-254-5610